



Ingeniería y Abastecimiento , S.A. de C.V.

Tel. 0181 81255625 , Fax. 0181 83726096 , gpuga@inasa.com.mx , www.inasa.mx

Chihuahua - Hermosillo - Mexico - Monclova - Monterrey - Puebla - Ramos Arizpe - Saltillo - San Luis - Silao - Toluca



13 ENERO 2021



	Número de Catalogo	Descripción	Almacén	Cantidad
1	2NC3H0122	CONTACTOR FUJI ELEC 2NC3H0122 ELECTRICAL SC-6N TYP	SILMO	1
2	3GC0T0M22	SC-N1/G MAGNETIC CONTACTOR	MATRIZST	53
3	3GC1Q0M22	3GC1Q0M22 CONTACTOR MAGNETICO NO REVERSIBLE 60 AMP	MATRIZST	31
4	3GC1Q0M22	3GC1Q0M22 CONTACTOR MAGNETICO NO REVERSIBLE 60 AMP	TOLST	1
5	3GC2H0M22	FUJI ELECTRIC CONTACTOR ODYSSEY 3GC3H0M22 DC24V	MATRIZST	16
6	3NC0T0122	SC-N1 AC110V ODYSSEY SERIES CONTACTOR 100-120VAC 5	MATRIZST	19
7	3NC1Q0122	CONTACTOR MAGNETICO NO REVERSIBLE SC-N2 3P BOBINA	MATRIZST	52
8	3NC1Q0222	3NC1Q0222 CONTACTOR 220V 2NO + 2NC FUJI	AAGMC	2
9	3NC1Q0E22	3NC1Q0E22 CONTACTOR MAGNETICO 3P 50AMP MCA. FUJI	MATRIZST	3
10	3NC2F0G22	SC-N2S AC120V ODYSSEY SERIES	MATRIZST	50
11	3NC2H0G22	3NC2H0G22 SC-N3 CONTACTOR ELECTROMAGNITOC 100AMP.	MATRIZST	30
12	3NC2T0122	SC-N4 AC110V ODYSSEY SERIES CONTACTOR 100-120VAC 5	MATRIZST	4
13	3NC2T0E22	FUJI MAGNETIC CONTACTOR SC-N4 COIL 24VAC 25AMP	MATRIZST	5
14	3NC3F0122	3NC3F0122 CONTACTOR ODYSSEY TAM 3F 150 AMPS BOBINA	MATRIZST	3
15	3NC3H0122	3NC3H0122 CONTACTOR 150 AMPS 2NC 2NO FUJI	MATRIZST	5
16	3NC3H0222	3NC3H0222 - CONTACTOR MAGNETICO - FUJI ELECTRIC	MATRIZST	1
17	3NC4F0122	3NC4F0122 CONTACTOR 200A, 100-10V, 2NO+2NC FUJI EL	MATRIZST	15
18	3NC4H0122	3NC4H0122 CONTACTOR FUJI ELECTRIC 2NA 2NC BOBINA 110V	MATRIZST	5
19	4GC0A0101	SC-03/G DC100V 1NC MCA FUJI ELECTRIC	MATRIZST	19
20	4GC0A0M10	4GC0A0M10 CONTACTOR MAGNETICO 11 AMPS. TIPO ABIERT	MATRIZST	27
21	4GC0G0102	SC-05/G DC100V 2NCP MCA FUJI ELECTRIC	MATRIZST	37
22	4GC0G0M11	4GC0G0M11 CONTACTOR MAGNETICO 13 AMPS. TIPO ABIERT	MATRIZST	134
23	4GC0G0M11	4GC0G0M11 CONTACTOR MAGNETICO 13 AMPS. TIPO ABIERT	SILMO	2
24	4GC0H0M11	CONTACTOR MAGNETICO SC-5-1/G # 4GC0H0M11 *FUJI	MATRIZST	23

25	4GCOQ0201	4GCOQ0201CONTACTOR MAGNETICO TAM 0Q 20 AMPS. 1NC B	MATRIZST	3
26	4GCOQ0M01	4GCOQ0M01 CONTACTOR MAGNETICO 20 AMPS. TIPO ABIERT	MATRIZST	20
27	4GCOQ0M10	4GCOQ0M10 CONTACTOR 7.5 KW 1NO 24V FUJI	MATRIZST	12
28	4GCOR0M10	4GCOR0M10 CONTACTOR 11KW 1NO 24V FUJI	MATRIZST	90
29	4GH4221	RELAY 4POLE 2NO/2NC 125VDC SH-4/G	MATRIZST	2
30	4NCOA0G10	4NCOA0G10 CONTACTOR MAGNETICO, 11 AMP. 120-130V, 1	MATRIZST	3
31	4NCOF0101	4NCOF0101 CONTACTOR MAGNETICO 110V 13A 1NC	MATRIZST	2
32	4NCOF0110	4NCOF0110 CONTACTOR MAGNETICO 110V 13A 1NO	MATRIZST	3
33	4NCOF0110	4NCOF0110 CONTACTOR MAGNETICO 110V 13A 1NO	SILMO	1
34	4NCOF0E01	4NCOF0E01 CONTACTOR MAGNETICO 24V 13A 1NC	MATRIZST	1
35	4NCOF0E10	4NCOF0E10 CONTACTOR MAGNETICO 24V 13A 1NO FUJI	MATRIZST	2
36	4NCOF0G01	4NCOF0G01 CONTACTOR MAGNETICO TAM 0F BOBINA 120-13	MATRIZST	2
37	4NCOF0G10	4NCOF0G10 CONTACTOR MAGETICO 3P 13A 1NA BOBINA 120	MATRIZST	3
38	4NCOG0102	4NCOG0102 CONTACTOR MAGNETICO 110-120V 2NC 20A FUJ	MATRIZST	17
39	4NCOG0111	4NCOG0111 CONTACTOR MAGNETICO 110V 1NO + 1NC FUJI	AAP6	2
40	4NCOG0111	4NCOG0111 CONTACTOR MAGNETICO 110V 1NO + 1NC FUJI	MATRIZST	1
41	4NCOG0G02	4NCOG0G02 CONTACTOR MAGNETICO DE 3 POLOS, 20 AMPS.	MATRIZST	3
42	4NCOGCK	KIT DE CONTACTORES PARA SC05 4NCOG-CK FUJI	MATRIZST	20
43	4NCOH1MC	4NCOH-1MC BOBINA 110-120V FUJI ELETIC	MATRIZST	9
44	4NCOHAMC	4NCOH-AMC BOBINA 100-110V FUJI ELECTRIC	MATRIZST	2
45	4NCOHCK	KIT DE CONTACTORES PARA SC51 ANCOH-CK FUJI	MATRIZST	20
46	4NCOHCMC	4NCOH-CMC BOBINA 400-440V FUJI ELECTRIC	MATRIZST	5
47	4NCOHEMC	4NCOH-EMC BOBINA 24V FUJI ELECTRIC	MATRIZST	6
48	4NCOHGMC	4NCOH-GMC BOBINA120-130V FUJI ELECTRIC	MATRIZST	8
49	4NCOQ0110	CONTACTOR MAGNETICO TAMAÑO 0Q 20A FUJI 4NCOQ0110	MATRIZST	1
50	4NK0ACY	4NK0ACY RELEVADOR DE SOBRE CARGA, BIMETALICO FUJI	MATRIZST	2
51	4NK0AE	4NK0AE OVERLOAD RELAY 0.48-0.72 AMP	AAP6	3
52	4NK0AH	4NK0AH OVERLOAD RELAY 0.95-1.45 AMP	AAP6	2
53	4NK0AH	4NK0AH OVERLOAD RELAY 0.95-1.45 AMP	MATRIZST	16
54	4NK0AH	4NK0AH OVERLOAD RELAY 0.95-1.45 AMP	SILMO	1
55	4NK0AJ	RELAY FUJI ELEC 4NK0AJ TK-ON 1.4-2.2A OVERLOAD	AAP6	2
56	4NK0AJ	RELAY FUJI ELEC 4NK0AJ TK-ON 1.4-2.2A OVERLOAD	MATRIZST	9
57	4NK0HT	RELAY FUJI ELEC 4NK0HT OVERLOAD TK-5-1 9-13AMPS	MATRIZST	1
58	4NW0A0AJ10K	STARTER FUJI ELECTRIC 4NW0A0AJ10K IEC MOTOR STARTE	SILMO	1
59	4SH422A	4SH422A - SH-4 AC100-110V 60HZ 2NO 2NC - FUJI ELEC	MATRIZST	2
60	4SH844A	4SH844A - CONTACTOR 100-110VAC 4NO - 4NC - FUJI EL	MATRIZST	5
61	4SH862A	4SH862A - CONTACTOR 100-110VAC 6NO - 2NC - FUJI EL	MATRIZST	1
62	AC09RX011L1	AC09-RX0/11L1 SWITCH TOTATIVO MCA. FUJI	MATRIZST	1
63	AC09RX011L1EA02	SWITCH FUJI ELEC AC09-RX0/11L1EA02 ROTARY SWITCH	SILMO	1
64	AC09RY120L1	SWITCH FUJI ELEC AC09-RY1/20L1 SWITCH ROTARY START	SILMO	1
65	AH164J2A11B	SWITCH POS KEY 1N/O+1N/C AUX KEY #AH164-J2A11B MCA	MATRIZST	4
66	AH164J2A11C	SELECTOR SWITCH 2 POSITION MAINTAINED W/ KEY REMOV	SILST	5
67	AH164J2B11A	SWITCH FUJI ELEC AH164-J2B11A KEY SELECTOR SWITCH	SILMO	2
68	AH164SLW11E3	AH164SLW11E3 SWITCH BOTON ILUMINADO AH164-SLW11E3	MATRIZST	4
69	AH164TGL011E3	AH164-TGLO11E3 BOTON ILUMINADO FLUSH RECTANGULAR N	MATRIZST	9
70	AH164TGL011E3	AH164-TGLO11E3 BOTON ILUMINADO FLUSH RECTANGULAR N	SILST	2
71	AH164TGLG11E3	AH164-TGLG11E3 BOTON ILUMINADO FLUSH RECTANGULAR V	MATRIZST	1

72	AH164TGLR11E3	AH164-TGLR11E3 BOTON ILUMINADO FLUSH RECTANGULAR R	MATRIZST	11
73	AH164TLG11E3	AH164TLG11E3 SWITCH BOTON ILUMINADO AH164-TLG11E3	MATRIZST	15
74	AH164TLR11E3	AH164-TLR11E3 BOTON RECTANGULAR ILUMINADO ROJO 24V	MATRIZST	5
75	AH164TLW11E3	AH164-TLW11E3 BOTON RECTANGULAR ILUMINADO BLANCO 2	MATRIZST	20
76	AH164TLY11E3	AH164TLY11E3 SWITCH BOTON ILUMINADO #AH164-TLY11E3	MATRIZST	5
77	AH164TX1BE	AH164-TX1BE ZUMBADOR SONIDO ALTO 12-24 AC/DC FUJI	MATRIZST	6
78	AH164ZOE3	AH164-ZOE3 LAMPARA INDICADORA EXTENDED ROUND FLAT	MATRIZST	3
79	AH164ZGE3	AH164-ZGE3 LAMPARA INDICADORA EXTENDED ROUND FLAT	MATRIZST	10
80	AH164ZRE3	AH164-ZRE3 LAMPARA INDICADORA EXTENDED ROUND FLAT	MATRIZST	10
81	AH164ZTOE3	AH164-ZTOE3 LAMPARA INDICADORA FLUSH RECTANGULAR F	MATRIZST	13
82	AH164ZTGE3	AH164-ZTGE3 LAMPARA INDICADORA FLUSH RECTANGULAR F	MATRIZST	7
83	AH164ZTRE3	AH164-ZTRE3 LAMPARA INDICADORA FLUSH RECTANGULAR F	MATRIZST	13
84	AH164ZTWE3	AH164-ZTWE3 LAMPARA INDICADORA FLUSH RECTANGULAR F	MATRIZST	12
85	AH164ZYE3	AH164-ZYE3 LAMPARA INDICADORA EXTENDED ROUND FLAT	MATRIZST	13
86	AH1652SFLG11E3	SWITCH FUJI ELEC AH165-2SFLG11E3 SWITCH PUSH BUTTO	MATRIZST	25
87	AH1652SFLG11E3	SWITCH FUJI ELEC AH165-2SFLG11E3 SWITCH PUSH BUTTO	SILMO	2
88	AH165J2A11A	SWITCH DE LLAVE MOD. AH165-J2A11A *FUJI	AAGMC	1
89	AH165J2A11A	SWITCH DE LLAVE MOD. AH165-J2A11A *FUJI	CHIVI	4
90	AH165J2A22A	AH165-J2A22A INTERRUPTOR SELECTOR DE LLAVE 2 POSIC	MATRIZST	5
91	AH165J2B11A	AH165-J2B11A SELECTOR SWITCH MARCA FUJI	MATRIZST	10
92	AH165JK3G22A	SWITCH FUJI ELECTRIC AH165-JK3G22A SWITCH AH165: O	SILMO	1
93	AH165JM2A22A	SWITCH SELECTOR 2 POSITION KEY WITH RECTANGULAR BE	AAP6	2
94	AH165P2B11	SWITCH FUJI AH165-P2B11 SELECTOR SWITCH 24VDC 0.7A	SILMO	1
95	AH165P2B22	AH165-P2B22 INTERRUPTOR SELECTOR DE PALANCA CORTA	MATRIZST	9
96	AH165SFG11	SWITCH FUJI ELECTRIC AH165-SFG11 PUSHBUTTON, GREEN	SILMO	1
97	AH165SFW11	SWITCH FUJI ELECTRIC AH165-SFW11 PUSHBUTTON, WHITE	SILMO	1
98	AH165SGFW11	SWITCH FUJI ELECTRIC AH165-SGFW11 PUSHBUTTON SWITC	SILMO	1
99	AH165SLG11E3	SWITCH FUJI ELECTRIC AH165-SLG11E3 PUSHBUTTON, GRE	MATRIZST	2
100	AH165SLG11E3	SWITCH FUJI ELECTRIC AH165-SLG11E3 PUSHBUTTON, GRE	SILST	2
101	AH165SLY11E3	SWITCH FUJI ELECTRIC AH165-SLY11E3 PUSHBUTTON, YEL	AAGMC	2
102	AH165SLY11E3	SWITCH FUJI ELECTRIC AH165-SLY11E3 PUSHBUTTON, YEL	AASMF	1
103	AH165SLY11E3	SWITCH FUJI ELECTRIC AH165-SLY11E3 PUSHBUTTON, YEL	MATRIZST	5
104	AH165SP2B11	SWITCH KNOB WITH SQUARE BEZEL 2 POS 90 DEG #AH165-	AAGMC	12
105	AH165SP2B11	SWITCH KNOB WITH SQUARE BEZEL 2 POS 90 DEG #AH165-	MATRIZST	2
106	AH165TFG11	SWITCH FUJI ELEC AH165-TFG11 SWITCH PUSH BUTTON GR	AAGMC	3
107	AH165TFR11	BOTON PULSADOR ROJO MOD. AH165-TFR11 *FUJI	AAGMC	4
108	AH165TFS11	BOTON PULSADOR AZUL MOD. AH165-TFS11 *FUJI	AAGMC	6
109	AH165TFW11	BOTON PULSADOR BLANCO MOD. AH165-TFW11 *FUJI	AAGMC	2
110	AH165TGFG11	BOTON PULSADOR VERDE 1NA-1NC AH165-TGFG11 FUJI ELE	MATRIZST	6
111	AH165TGFR11	BOTON PULSADOR ROJO 1NA-1NC AH165-TGFR11 FUJI ELEC	MATRIZST	8
112	AH165TGFW11	BOTON PULSADOR BLANCO 1NA-1NC AH165-TGFW11 FUJI EL	MATRIZST	14
113	AH165TGFW11	BOTON PULSADOR BLANCO 1NA-1NC AH165-TGFW11 FUJI EL	SILMO	1
114	AH165TGLW11E3	SWITCH FUJI ELEC AH165-TGLW11E3 PUSH BUTTON OPERAT	SILMO	2
115	AH165TLG11E3	BOTON PULZADOR CON LAMPARA VERDE MOD.AH165TLG11E3	SILMO	2
116	AH165TLW11E3	BOTON PULSADOR CON LAMPARA BLANCO MOD.AH165-TLW11E	SILMO	2
117	AH165TLY11E3	SWITCH FUJI ELEC AH165-TLY11E3 SWITCH,PUSH BUTTON;	SILMO	2
118	AH165ZSOE3	LAMP FUJI ELEC AH165-ZSOE3 LAMP 24V DC OIL-TIGHT T	SILMO	1

119	AH165ZSRE3	LAMP FUJI ELEC AH165-ZSRE3 LAMP 24V DC OIL-TIGHT T	SILMO	2
120	AH165ZSWE3	LAMP FUJI ELEC AH165-ZSWE3 LAMP 24V DC OIL-TIGHT T	SILMO	1
121	AH165ZT0E3	AH165-ZT0E3 LAMPARA PILOTO 16MM SIN TRANSFORMADOR	MATRIZST	18
122	AH165ZTGE3	LAMPARA RECTANGULAR VERDE 24VDC LED #AH165-ZTGE3 M	SILMO	2
123	AH165ZTRE3	AH165-ZTRE3 LAMPARA PILOTO 16MM SIN TRANSFORMADOR	MATRIZST	14
124	AH165ZTWE3	AH165-ZTWE3 LAMPARA PILOTO 16MM SIN TRANSFORMADOR	MATRIZST	17
125	AH22PC3B172	AH22PC3B172 SWITCH SELECTOR # AH22-PC3B172 FUJI	MATRIZST	3
126	AH30P3B22	AH30P3B22 SWITCH SELECTOR # AH30-P3B22 FUJI	MATRIZST	3
127	AHX779B	AHX779-B PALANCA ROTATORIA PARA INTERRUPTOR TERMOM	MATRIZST	5
128	AM22V0E02R	MOD. AM22V0E-02R, BOTON PARO DE EMERGENCIA FUJI	MATRIZST	2
129	AR2210B	BOTON NEGRO MOD.AR22-10B MCA .FUJI, (AR22FOR11B)	MATRIZST	3
130	AR22E0L10E3G	SWITCH, PUSHBUTTON MFG: FUJI ELEC PN: AR22E0L-10E3	AAP6	4
131	AR22E0L10E3G	SWITCH, PUSHBUTTON MFG: FUJI ELEC PN: AR22E0L-10E3	MATRIZST	15
132	AR22E0L10E4A	PUSHBUTTON OPERATOR ILLUMINATED	MATRIZST	2
133	AR22E0L10E4R	BOTON PULSADOR 22MM, ILUMINADO, 1 NO , VOLTAJE 110V, ROJO	MATRIZST	3
134	AR22E0L11E3R	BOTON DE CONTROL 22MM DIAM. ILUMINADO 24V AC/DC EX	MATRIZST	20
135	AR22E0L11E3Y	BOTON DE CONTROL 22MM DIAM. ILUMINADO 24V AC/DC EX	MATRIZST	10
136	AR22E0R01R	PUSHBUTTON SWITCH EXTENDED ROUND HEAD #AR22E0R-01R	MATRIZST	14
137	AR22E0R01R	PUSHBUTTON SWITCH EXTENDED ROUND HEAD #AR22E0R-01R	SILMO	1
138	AR22E5L20E3W	AR22E5L-20E3W BOTON PULSADOR ILUMUNADO FUJI ELECTR	MATRIZST	10
139	AR22F0L10E3W	SWITCH MOD. AR22F0L-10E3W	CHIVI	1
140	AR22F0L10E4G	MOD. AR22F0L10E4G PUSH BUTTON FUJI	MATRIZST	8
141	AR22F0L11E3A	AR22F0L-11E3A BOTON22MM FUJI ELECTRIC	MATRIZST	3
142	AR22F0L11E3G	AR22F0L-11E3G BOTON22MM FUJI ELECTRIC	MATRIZST	20
143	AR22F0L11E4A	BOTON PULSADOR, NARANJA, 1 NO + 1 NC, 110V, 22MM	MATRIZST	2
144	AR22F0M10E3W	AR22F0M-10E3W BOTON ILUMINADO CUADRADO 22MM COLOR	MATRIZST	24
145	AR22F0P10E3G	AR22F0P-10E3G BOTON DE CONTROL, RAZANTE, GUARDA CU	MATRIZST	2
146	AR22F0R10B	SWITCH PUSHBUTTON OPERATOR 1NO CONTACTS BLACK #AR2	AAP6	2
147	AR22F0R10B	SWITCH PUSHBUTTON OPERATOR 1NO CONTACTS BLACK #AR2	SILST	1
148	AR22F0R10G	AR22F0R-10G BOTON CONTROL, RAZANTE 22MM, VERDE, 1N	MATRIZST	8
149	AR22F0R10R	SWITCH FUJI ELEC AR22F0R-10R PUSHBUTTON SWITCH FL	SILMO	5
150	AR22F0R10R	SWITCH FUJI ELEC AR22F0R-10R PUSHBUTTON SWITCH FL	SILST	2
151	AR22F0R10W	PUSHBUTTON SWITCH FLUSH ROUND HEAD #AR22F0R-10W MC	SILMO	1
152	AR22F0R10Y	AR22F0R-10Y BOTÓN PULSADOR DE CABEZA REDONDA FUJI	SILMO	1
153	AR22F0R11B	BOTON DE CONTROL 22MM CORTO MOMENTANEO NEGRO 1NA-1NC	MATRIZST	10
154	AR22F0R11G	BOTON DE CONTROL 22MM DIAM. TIPO CORTO MOMENTANEO	MATRIZST	53
155	AR22F0R11R	BOTON DE CONTROL 22MM DIAM. TIPO CORTO MOMENTANEO	MATRIZST	28
156	AR22F0R11W	BOTON DE CONTROL 22MM DIAM. TIPO CORTO MOMENTANEO	MATRIZST	5
157	AR22F0S10G	AR22F0S-10G BOTON PULSADOR 22MM CUADRADO VERDE 1NO	MATRIZST	15
158	AR22F5M10E3A	AR22F5M-10E3A BOTON PULSADOR 22 MCA. FUJI	MATRIZST	20
159	AR22F5M10E3W	AR22F5-M10E3W BUTTON,PUSH FUJI ELECTRIC	MATRIZST	10
160	AR22G2L11E3G	BOTON DE CONTROL 22MM DIAM. ILUMINADO 24V AC/DC EX	MATRIZST	5
161	AR22G3R10B	SWITCH, PUSHBUTTON MFG: FUJI ELEC PN: AR22G3R-10B	MATRIZST	10
162	AR22G4L10E3G	SWITCH FUJI ELEC AR22G4L-10E3G ILLUMINATED PUSHBUT	MATRIZST	2
163	AR22G4L10E3G	SWITCH FUJI ELEC AR22G4L-10E3G ILLUMINATED PUSHBUT	SILMO	2
164	AR22G4L10E3R	AR22G4L-10E3R SWITCH PUSH BUTTON N.O. SPST EXTEND	MATRIZST	10
165	AR22G4L11E3G	MOD. AR22G4L11E3G, PUSH BUTTON FUJI	MATRIZST	7

166	AR22G4L11E3W	AR22G4L11E3W BOTON PULSADOR ILUMINADO FUJI ELECTRI	MATRIZST	10
167	AR22G4L20E3S	AR22G4L-20E3S ILLUMINATION PUSH BUTTON SWITCH FU	MATRIZST	6
168	AR22JAR2A10A	AR22JAR2A10A - SELECTOR CON 2 POSICIONES NO/NC - F	MATRIZST	10
169	AR22JR2A10A	MOD. AR22JR-2A10A, INTERRUPTOR FUJI	AAP6	4
170	AR22JR2A10A	MOD. AR22JR-2A10A, INTERRUPTOR FUJI	MATRIZST	8
171	AR22JR2D11A	SWITCH FUJI ELEC AR22-JR-2D11A KEY	SILST	2
172	AR22M0R10Y	AR22M0R-10Y BOTON DE CONTROL AMARILLO 1NA FUJI	MATRIZST	50
173	AR22M0R11G	BOTON DE CONTROL 22MM DIAM. IP40 TIPO HONGO 40MM.	MATRIZST	11
174	AR22M0R11R	AR22M0R-11R PUSH BUTTON EMERGENCY STOP FUJI ELECTR	MATRIZST	14
175	AR22M0R22B	AR22M0R-22B PUSH BUTTON, MUSHROOM HEAD, 22MM, 2NO+	MATRIZST	40
176	AR22M3R11G	AR22M3R-11 BOTON DE CONTROL TIPO HONGO COLOR VERDE	MATRIZST	5
177	AR22PCR311CB	AR22PCR-311CB SELECTOR 3POSC. 2NC/2NO *FUJI	MATRIZST	25
178	AR22PCR3172B	SWITCH FUJI ELEC AR22-PCR3172B SELECTOR 3 POSITION	AAGMC	2
179	AR22PCR3174B	AR22PCR3174B PUSHBUTTON/SELECTOR SWITCH 10AMP 600V	MATRIZST	10
180	AR22PCR441CB	AR22PCR-441CB SELECTOR SWITCH MCA. FUJI	MATRIZST	15
181	AR22PR201B	POS. SELECTOR SWITCH MAINTAINED	MATRIZST	7
182	AR22PR210B	SWITCH FUJI ELEC AR22PR-210B SELECTOR 2 POSITION M	MATRIZST	12
183	AR22PR211B	AR22PR-211B INTERRUPTOR SELECTOR 22MM DIAM. NO ILU	AAGMC	1
184	AR22PR211B	AR22PR-211B INTERRUPTOR SELECTOR 22MM DIAM. NO ILU	AASMF	2
185	AR22PR211B	AR22PR-211B INTERRUPTOR SELECTOR 22MM DIAM. NO ILU	MATRIZST	69
186	AR22PR320B	INTERRUPTOR SELECTOR 22MM DIAM. NO ILUMINADO 3 POS	MATRIZST	1
187	AR22Q2R02R	SWITCH MOD. AR22Q2R-02R	CHIVI	1
188	AR22Q2R02R	SWITCH MOD. AR22Q2R-02R	MATRIZST	1
189	AR22S2R20B	SWITCH FUJI ELEC AR22-S2R-20B SELECTOR	MATRIZST	10
190	AR22V2R01B	AR22V2R-01B PUSHBUTTON 40MM BLACK PUSH LOCK 1 N.C.	MATRIZST	9
191	AR22V2R01R	AR22V2R01R BOTON COLO ROJO MCA FUJI	AAGMC	4
192	AR22V2R01R	AR22V2R01R BOTON COLO ROJO MCA FUJI	MATRIZST	5
193	AR22V2R11R	SWITCH FUJI ELEC AR22-V2R11R PUSHBUTTON OPERATOR P	AAGMC	2
194	AR22VQR12R	AR22VQR-12R PARO DE EMERGENCIA 22MM ROJO FUJI ELEC	MATRIZST	35
195	AR22VSR02R	SWITCH FUJI ELEC AR22VSR-02R PUSH LOCK, TURN RESET	AAGMC	2
196	AR22VSR11R	AR22VSR-11R BOTON22MM FUJI ELECTRIC	MATRIZST	5
197	AR22WR122B	AR22WR-122B SWITCH SELECTOR DE 3 POSICIONES RETORN	MATRIZST	2
198	AR22WR320B	INTERRUPTOR SELECTOR 22MM DIAM. NO ILUMINADO 3 POS	MATRIZST	5
199	AR30A7NA0A0B	AR30A7N-A0A0B MONOLEVER SWITCH MCA FUJI ELECTRIC	MATRIZST	4
200	AR30B1R11B	AR30B1R-11B PUSH BUTTON 30MM DIAMETRO CABEZA 75MM	MATRIZST	10
201	AR30B1R11G	BOTON DE CONTROL 30MM DIAM. TIPO GRAN HONGO 75MM.	MATRIZST	6
202	AR30B1R11Y	BOTON DE CONTROL 30MM DIAM. IP40 TIPO HONGO 40MM.	MATRIZST	6
203	AR30B2R11GZM	AR30B2R-11GZM PUSH BUTTON FUJI ELECTRIC	MATRIZST	5
204	AR30B2R22BZM	AR30B2R-22BZM PUSH BUTTON FUJI ELECTRIC	MATRIZST	5
205	AR30E0L10E3YZM	AR30E0L-10E3YZM BOTON PULSADOR AMARILLO 1NO FUJI	MATRIZST	5
206	AR30E0L11E3G	AR30E0L-11E3G BOTON 30MM FUJI ELECTRIC	MATRIZST	2
207	AR30E0L11E3GZM	AR30E0L-11E3GZM BOTON DE CONTROL ILUMINADO 30MM. T	MATRIZST	2
208	AR30E0L11E3RZM	AR30E0L-11E3RZM BOTON DE CONTROL ILUMINADO 30MM. T	MATRIZST	2
209	AR30E0L11E3WZM	AR30E0L-11E3WZM BOTON DE CONTROL ILUMINADO 30MM. T	MATRIZST	8
210	AR30F0R10G	BUTTON FUJI ELEC AR30F0R-10G PUSH GREEN 1 NO CONTA	MATRIZST	5
211	AR30F0R10SZM	AR30F0R-10SZM BOTON DE CONTROL NO ILUMINADO 30MM.	MATRIZST	3
212	AR30F0R11BZM	AR30F0R-11BZM PUSH BUTTON FUJI ELECTRIC	MATRIZST	6

213	AR30FOR11G	BOTON DE CONTROL 30MM DIAM. IP40 TIPO CORTO CONTAC	MATRIZST	13
214	AR30FOR11GZM	AR30FOR-11GZM PUSH BUTTON SWITCH FUJI ELECTRIC	MATRIZST	36
215	AR30FOR11R	BOTON DE CONTROL 30MM DIAM. IP40 TIPO CORTO CONTAC	MATRIZST	61
216	AR30FOR11RZM	AR30FOR-11RZM BOTON DE CONTROL NO ILUMINADO 30MM.	MATRIZST	7
217	AR30FOR11YZM	AR30FOR-11YZM PUSH BUTTON SWITCH FUJI ELECTRIC	MATRIZST	46
218	AR30G1R11G	AR30G1R-11G BOTON30MM FUJI ELECTRIC	MATRIZST	5
219	AR30G2L11E3G	AR30G2L-11E3G PUSH BUTTON ILUMINADO FUJI ELECTRIC	MATRIZST	11
220	AR30G3L10E3G	AR30G3L-10E3G BOTON DE CONTROL 30MM. ILUMINADO LED	MATRIZST	7
221	AR30G3L11E3G	AR30G3L-11E3G BOTON RAZANTE, 30MM, GUARDA COMPLETA	MATRIZST	3
222	AR30G3L11E3R	AR30G3L11E3R BOTON DE CONTROL ROJO FUJI ELECTRIC	MATRIZST	5
223	AR30G4L10E3G	MOD. AR30G4L-10E3G, PUSH BUTTON FUJI	MATRIZST	10
224	AR30JAR2A11BZM	AR30JAR-2A11BZM KEY SWITCH FUJI ELECTRIC	MATRIZST	1
225	AR30JR0A11A	AR30JR-0A11A SELECTOR 30MM FUJI ELECTRIC	MATRIZST	5
226	AR30JR2A11B	AR30JR-2A11B SELECTOR 30MM. DE LLAVE 2 POS. MANTEN	MATRIZST	2
227	AR30JR3A11AZM	AR30JR-3A11AZM KEY SWITCH FUJI ELECTRIC	MATRIZST	2
228	AR30M0R11G	BOTON DE CONTROL 30MM DIAM. IP40 TIPO HONGO 40MM.	MATRIZST	4
229	AR30M0R11YZM	AR30M0R-11YZM PUSH BUTTON 30MM AMARILLO FUJI ELECT	MATRIZST	8
230	AR30PR011BZM	AR30PR-011BZM SELECTOR SWITCH FUJI ELECTRIC	MATRIZST	1
231	AR30PR211B	INTERRUPTOR SELECTOR 30MM DIAM. NO ILUMINADO 2 POS	MATRIZST	48
232	AR30S2R22BZM	AR30S2R-22BZM BOTON DE CONTROL CON SELECTOR 30MM D	MATRIZST	9
233	AR30V0R11R	MOD. AR30V0R-11R PUSH BUTTON FUJI ELECTRIC	MATRIZST	6
234	AR30V1R22RZM	AR30V1R-22RZM BOTON PARO DE EMERGENCIA 30MM FUJI E	MATRIZST	2
235	AR30V2R01B	BOTON PARO DE EMERGENCIA, 1NC, NEGRO, 30MM	MATRIZST	1
236	AR30V2R01R	AR30V2R01R BOTON DE EMPUJE # AR30V2R-01R *FUJI	MATRIZST	9
237	AR30V2R10R	SWITCH FUJI ELECTRIC AR30V2R-10R PUSHBUTTON, RED M	AAGMC	3
238	AR30V5R22RZM	AR30V5R-22RZM BOTON PARO EMERGENCIA 30MM FUJI ELEC	MATRIZST	1
239	AR9B290	BLOCK-CONT. 1NO. MOD. AR9B290 *FUJI	MATRIZST	33
240	AR9B291	BLOCK-CONT. 1NC. MOD. AR9B291 *FUJI	MATRIZST	118
241	AR9B291	BLOCK-CONT. 1NC. MOD. AR9B291 *FUJI	SILMO	1
242	AR9C001G	MICA PARA BOTON VERDE AR22F0R, F5Y, G2R, AR30F0R,	MATRIZST	4
243	AR9C012G	LENTE DE PLASTICO COLOR VERDE 22MM DIAM. PARA LAMP	MATRIZST	20
244	AR9C022A	AR9C022-A LLAVES DE REEMPLAZO TIPO A PARA SELECTOR	MATRIZST	10
245	AR9R008	AR9R008 PROTECTOR AMARILLO PARA PARO DE EMERGENCIA	MATRIZST	40
246	BLA005	BLA005 FUSIBLE TIPO BOTELLA 5 AMPS 600V FUJI ELECTRIC	MTYVI	1
247	BM3RHB020	MMS 20A 45MM ROTARY	MATRIZST	1
248	BM3RSB004	MANUAL MOTOR STARTER ADJUSTABLE CURRENT RANGE IE 2	MATRIZST	2
249	BM3RSB032	BM3RSB-032 ARRANCADOR 24-32A FUJI ELECTRIC	MATRIZST	4
250	BM3RSBP63	MANUAL MOTOR STARTER 0.4-0.63AMP	MATRIZST	2
251	BW125JAGU3P050	BW125JAGU-3P050 INTERRUPTOR 3 POLOS 50 AMPS. FUJI	MATRIZST	1
252	BW125JAGU3P075	BW125JAGU-3P075 CIRCUIT BREAKER MCA. FUJI	MATRIZST	2
253	BW125JAGU3P100	CIRCUIT BREAKER 100AMP 3POLE 690VAC 250VDC	MATRIZST	2
254	BW125RAGU2P030	CIRCUIT BREAKER THERMAL MAGNETIC 2POLE 30A 690VAC	MATRIZST	1
255	BW125RAGU2P100	CIRCUIT BREAKER THERMAL MAGNETIC 2POLE 100A 690VAC	MATRIZST	1
256	BW125RAGU3P015	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 15A 690VAC/	MATRIZST	1
257	BW125RAGU3P020	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 20A 690VAC/	MATRIZST	1
258	BW125RAGU3P030	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 30A 690VAC/	MATRIZST	1
259	BW125RAGU3P040	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 40A 690VAC/	MATRIZST	1

260	BW125RAGU3P050	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 50A 690VAC/	MATRIZST	1
261	BW125RAGU3P060	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 60A 690VAC/	MATRIZST	1
262	BW125RAGU3P075	BW125RAGU-3P075 INTERRUPTOR TERMOMAGNETICO, 3 POLO	MATRIZST	1
263	BW125RAGU3P080	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 80A 690VAC/	MATRIZST	1
264	BW125RAGU3P100	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 100A 690VAC	MATRIZST	1
265	BW125RAGU3P125	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 125A 690VAC	MATRIZST	1
266	BW250RAGU3P150	CIRCUIT BREAKER THERMAL MAGNETIC 3POLE 150A 690VAC	MATRIZST	1
267	BW250RAGU3P175	BW250RAGU-3P175 INTERRUPTOR TERMOMAGNETICO, 3 POLO	MATRIZST	1
268	BW250RAGU3P225	BW250RAGU-3P225 INTERRUPTORTERMOMAGNETICO FUJIELEC	MATRIZST	1
269	BW32AAG2P005	BW32AAG-2P005 INTERRUPTOR TERMOMAGNETICO G-TWIN 2	MATRIZST	1
270	BW32AAG3P010	INTERRUPTOR 3P, 10A, FUJI ELECTRIC	MATRIZST	2
271	BW32SAG2P005	BW32SAG-2P005 BREAKER 5 A 2 POLE	MATRIZST	1
272	BW32SAG2P010	BW32SAG-2P010 INTERRUPTOR TERMOMAGNETICO, 2 POLOS,	MATRIZST	1
273	BW32SAG2P020	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 20A 690VAC/250VDC	MATRIZST	1
274	BW32SAG2P030	BW32SAG-2P030 NO FUSE BREAKER MCA. FUJI	MATRIZST	2
275	BW32SAG3P005	BW32SAG-3P005 BREAKER 5 A 3 POLE	MATRIZST	1
276	BW32SAG3P010	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 10A 690VA	MATRIZST	8
277	BW32SAG3P015	BW32SAG-3P015 BREAKER 15 A 3 POLE	MATRIZST	1
278	BW32SAG3P020	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 20A 690VAC/250VDC	MATRIZST	1
279	BW400RAGU3P400	BW400RAGU-3P400 INTERRUPTOR TERMOMAGNETICO 400 AMP	MATRIZST	1
280	BW50RAG2P010	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 10A 690VA	MATRIZST	1
281	BW50RAG2P015	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 15A 690VA	MATRIZST	1
282	BW50RAG2P020	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 20A 690VA	MATRIZST	1
283	BW50RAG3P050	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 50A 690VA	MATRIZST	1
284	BW50RAGU2P003	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 3A 690VAC	MATRIZST	5
285	BW50RAGU2P005	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 5A 690VAC	MATRIZST	5
286	BW50RAGU2P010	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 10A 690VAC/250VDC	MATRIZST	1
287	BW50RAGU2P015	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 15A 690VA	MATRIZST	2
288	BW50RAGU2P020	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 20A 690VA	MATRIZST	1
289	BW50RAGU2P030	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 30A 690VA	MATRIZST	1
290	BW50RAGU2P050	BW50RAGU-2P050 NO FUSE BREAKER	MATRIZST	1
291	BW50RAGU3P005	BW50RAGU-3P005 CIRCUIT BREAKER HYDRAULIC MAGNETIC	MATRIZST	4
292	BW50RAGU3P010	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 10A 690VA	MATRIZST	2
293	BW50RAGU3P015	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 15A 690VA	MATRIZST	1
294	BW50RAGU3P020	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 20A 690VA	MATRIZST	1
295	BW50RAGU3P040	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 30A 690VA	MATRIZST	1
296	BW50RAGU3P050	BW50RAGU-3P050 CIRCUIT BREAKER HYDRAULIC MAGNETIC	MATRIZST	2
297	BW50SAG2P005	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 5A 690VAC	MATRIZST	1
298	BW50SAG2P010	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 10A 690VA	MATRIZST	1
299	BW50SAG2P015	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 15A 690VA	MATRIZST	1
300	BW50SAG2P020	CIRCUIT BREAKER HYDRAULIC MAGNETIC 2POLE 20A 690VA	MATRIZST	1
301	BW50SAG3P005	BW50SAG-3P005 NO FUSE BREAKER	MATRIZST	2
302	BW50SAG3P010	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 10A 690VA	MATRIZST	1
303	BW50SAG3P030	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 30A 690VA	MATRIZST	1
304	BW63SAG3P60A	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 60A 690VA	MATRIZST	1
305	BW9N0CA	MOLDED CASE CIRCUIT BREAKERS HANDLES	MATRIZST	2
306	BW9V0CA	MANIJA DE DESCONEXION ROTATORIO NEMA12 #BW9V0CA MC	MATRIZST	9

307	BW9V0GA	MOD. BW9V0GA, MANIJA ROTATORIA FUJI ELECTRIC	MATRIZST	6
308	BW9VOHA	BW9VOHA MANIJA DE INTERRUPTOR PRINCIPAL DE GIRO MA	MATRIZST	3
309	BW9W1SG0R	ELECTROMECHANICAL SWITCH AUXILIARY SWITCH	MATRIZST	1
310	BZ0LRE22GA	LINK MODULE FOR ELECTRICALLY CONNECTING BM3RH MMS	MATRIZST	2
311	BZ6V10D	CIRCUIT PROTECTION FOR EXTERNAL OPERATING HANDLE	MATRIZST	23
312	BZ6V10D	CIRCUIT PROTECTION FOR EXTERNAL OPERATING HANDLE	SILMO	2
313	BZ6WL10CA	SWITCH FUJI ELEC BZ6WL10CA AUXILIARY SWITCH	MATRIZST	10
314	CP30FM1P002	CP30FM-1P002 CONRUIT PROTECT 1P 2AMP FUJI	MATRIZST	8
315	CP30FM1P002WA	CP30FM-1P002WA CIRCUIT PROTECTOR 2A. 1NO FUJI	MATRIZST	64
316	CP30FM1P003	CP30FM-1P003 MINI CIRCUIT BREAKER 3 AMP, 1 POLO, F	MATRIZST	20
317	CP30FM1P005	CP30FM-1P005 CIRCUITO PROTECTOR 1 POLES 5 AMPS FUJ	MATRIZST	9
318	CP30FM1P005WA	CP30FM-1P005WA INTERRUPTOR 1 POLO 5 AMP. 1NO FUJI	MATRIZST	11
319	CP30FM1P007	CP30FM-1P007 CIRCUIT PROTECT 1P, 7 AMP MCA FUJI ELECTRIC	MATRIZST	10
320	CP30FM1P010	CP30FM-1P010 CIRCUIT PROTECT 1P, 10 AMP MCA FUJI ELECTRIC	MATRIZST	10
321	CP30FM1P010WA	CP30FM-1P010WA INTERRUPTOR 1POLO 10AM 1NO FUJI EL	MATRIZST	10
322	CP30FM1P015WA	INTERRUPTOR 1P AC250V DC65V 15A #CP30FM-1P015WA MC	MATRIZST	10
323	CP30FM1P020	CIRCUIT BREAKER 1 POLO, 20A, 250VAC MCA FUJI ELECT	MATRIZST	1
324	CP30FM1P0P1	CIRCUIT BREAKER CP30FM-1P0P1 FUJI ELECTRIC	MATRIZST	2
325	CP30FM2P001WA	CP30FM-2P001WA CIRCUIT PROTECTOR WA 1A 2P	MATRIZST	5
326	CP30FM2P003	CP30FM-2P003 CIRCUIT PROTECTOR 3A 2P	MATRIZST	9
327	CP30FM2P003WA	PROTECTOR CP32FM-3W (CP30FM-2P003WA) *FUJI ELECTRI	MATRIZST	5
328	CP30FM2P005	CP30FM-2P005 CIRCUIT PROTECTOR 5A 2 POLE	MATRIZST	10
329	CP30FM2P005WA	CP30FM-2P005WA MINI CIRCUIT BREAKER 2 POLOS 5 AMPS	MATRIZST	10
330	CP30FM2P007	CIRCUIT BREAKER CP30FM-2P007 FUJI ELECTRIC	MATRIZST	1
331	CP30FM2P010	CP30FM-2P010 CIRCUIT PROTECTOR FUJI ELECTRIC	MATRIZST	5
332	CP30FM2P010WA	CP30FM-2P010WA INTERRUPTOR TERMOMAGNETICO 2 POLOS	MATRIZST	10
333	CP30FS1P005WA	BREAKER FUJI CP30FS-1P005WA	SILMO	3
334	CP31E1W	CP31E/1W CIRCUIT BREAKER 1 POLO 1AMP 250V MARCA FU	MATRIZST	2
335	CP31FM10	CIRCUIT PROTECTOR 1P 10A #CP31FM/10 MCA FUJI (NUE	SILMO	2
336	CP31FM15	CIRCUIT BREAKER 1POLE 15A 250VAC (REEMPLAZO CP30FM	SILMO	1
337	CP31FM20	CIRCUIT BREAKER 1POLE 20A 250VAC, MODELO NUEVO CP3	MATRIZST	1
338	CP32D10	CP32D10 PROTECTOR DE CIRCUITO 10AT #CP32D/10 FUJI	MATRIZST	1
339	CP32D5W	CP32D5W PROTECTOR DE CIRCUITO 5AT #CP32D/5W FUJI	MATRIZST	1
340	CP32E1	CP32E/1 CIRCUIT BREAKER 2 POLOS 1AMP 250V MARCA FU	MATRIZST	1
341	CP32E1WD	CP32E/1WD CIRCUIT BREAKER 2 POLOS 1AMP 250V MARCA	MATRIZST	5
342	CP32FM1	CIRCUIT BREAKER 2POLE 1A 250VAC	MATRIZST	2
343	CP32FM2	CIRCUIT BREAKER 2POLE 2A 250VAC	MATRIZST	1
344	CP32FM20	CIRCUIT BREAKER 2POLE 20A 250VAC	MATRIZST	2
345	CP32FM3	CIRCUIT BREAKER 2POLE 3A 250VAC	MATRIZST	2
346	CP32FM5	CIRCUIT BREAKER 2POLE 5A 250VAC	MATRIZST	2
347	CR6L150UL	FUSIBLE 600V 150AMP MOD. CR6L150UL	MATRIZST	5
348	CR6L50UL	FUSIBLE 50 A AC600V DC680V FUJI CR6L-50/UL	MTYVI	3
349	DR16F0NE3G	DR16F0N-E3G SQUARE LAMP FUJI ELECTRIC	MATRIZST	2
350	DR16F0NE3R	DR16F0N-E3R LUZ PILOTOTO CUADRADA FUJI ELECTRIC	MATRIZST	2
351	DR16F0NE3W	DR16F0N-E3W SQUARE LAMP FUJI ELECTRIC	MATRIZST	2
352	DR22B8EB	DR22B8-EB ALARMA ZUMBADOR 80DB 12 to 24 VAC/VDC, 22MM, PANEL MOUNT, PLASTIC H	MATRIZST	4
353	DR22D0LE3A	MOD. DR22D0L-E3A, BOTON INDICADO FUJI ELECTRIC	MATRIZST	8



354	DR22D0LE3G	DR22D0L-E3G SWITCH INDICATORS 24VAC/24VDC LED ROUN	SILST	10
355	DR22D0LE3R	DR22D0L-E3R LAMPARA INDICADORA 24V ROJA	MATRIZST	7
356	DR22D0LE3W	DR22D0L-E3W PILOT LAMP FUJI ELECTRIC	MATRIZST	4
357	DR22D0LE3Y	DR22D0L-E3Y PILOT LIGHT YELLOW FUJI ELECTRIC	MATRIZST	20
358	DR22D0LH3W	DR22D0L-H3W PILOT LAMP FUJI ELECTRIC	MATRIZST	7
359	DR22D0LT3W	DR22D0L-T3W SQUARE LAMP WHITE 400-440VAC FUJI	MATRIZST	10
360	DR22E3LE3G	LAMPARA INDICADORA 22MM DIAM. TIPO LED COLOR VERDE	MATRIZST	2
361	DR22E3LE3Y	LAMPARA INDICADORA 22MM DIAM. TIPO LED COLOR AMARI	MATRIZST	5
362	DR22E3ME3A	DR22E3M-E3A LAMPARA INDICADORA 24 VDC NARANJA FUJI	MATRIZST	13
363	DR22E3ME3G	DR22E3M-E3G LAMPARA INDICADORA 24 VDC VERDE FUJI	MATRIZST	8
364	DR22E3ME3R	DR22E3M-E3R LAMPARA INDICADORA 24 VDC ROJO FUJI	MATRIZST	15
365	DR22E3ME3Y	DR22E3M-E3Y LAMPARA INDICADORA 24VDC AMARILLA FUJI	MATRIZST	22
366	DR22F4ME3A	DR22F4M-E3A LAMPARA INDICADORA 22 MM FUJI ELECTRIC	MATRIZST	2
367	DR22F4ME3G	DR22F4M-E3G LAMPARA CUADRADA 22MM VERDE FUJI ELECT	MATRIZST	2
368	DR22F4ME3R	DR22F4M-E3R LAMPARA CUADRADA FUJI ELECTRIC	MATRIZST	2
369	DR30D0LE3AZM	LUZ PILOTO DOMO 30 MM, NARANJA GUARDA METALICA, 24V VOLTS	MATRIZST	2
370	DR30D0LE3GZM	DR30D0L-E3GZM LAMPARA INDICADORA 30MM FUJI ELECTRI	MATRIZST	1
371	DR30D0LE3WZM	DR30D0L-E3WZM LAMPARA INDICADORA BLANCA FUJI ELECT	MATRIZST	5
372	DR30D0LH3W	DR30D0L-H3W 30MM DOME PILOT LIGHTS WHITE, 100-120	MATRIZST	2
373	DR30D0LV3WZM	DR30D0L-V3WZM FUJI ELECTRIC	MATRIZST	2
374	DR30D0LV4W	DR30D0L-V4W PILOT LAMP 480V. FUJI ELECTRIC	MATRIZST	10
375	DR9P241W	DR9P241-W PLACA FUJI ELECTRIC	MATRIZST	48
376	EW100EAGU3P060B	EW100EAGU-3P060 INTERRUPTOR CON FALLA A TIERRA 3 P	MATRIZST	1
377	EW32AAG2P015B	EW32AAG-2P015B INTERRUPTOR TERMOMAGNETICO EARTH LE	MATRIZST	2
378	EW32AAG3P030B	EW32AAG-3P030B INTERRUPTOR CON FALLA A TIERRA 3 PO	MATRIZST	1
379	EW50AAG2P040B	CIRCUIT BREAKER 2P 40AMP MCA. FUJI	MATRIZST	2
380	EW50RAGU3P003B	CIRCUIT BREAKER HYDRAULIC MAGNETIC 3POLE 3A 440VAC	MATRIZST	1
381	EW50RAGU3P020K	EW50RAGU-3P020K BREAKER FUJI ELEC	SILMO	1
382	EW50SAG3P050K	EW50SAG-3P050K INTERRUPTOR TERMOMAGNETICO EARTH LE	MATRIZST	1
383	EW63EAG3P060A	EW63EAG-3P060A CIRCUIT BREAKER 3P 60A 240V MCA. FU	MATRIZST	4
384	FD511114	INDICADOR NUMERICO DE NIVEL MOD. FD5111-14 *FUJ1 E	MATRIZST	2
385	FRN0002C2S7U	CONTROLADOR VELOCIDAD 1.5 AMP. 240 V FUJI FRN0002C2S-7U	MTYVI	2
386	FRN001E1S4U	FRN001E1S-4U VARIABLE FREQUENCY DRIVE, 1 HP, 380-4	SILMO	1
387	HH52PFLDC24V	RELAY FUJI HH52P-FL-DC24V CONTROL MINIATURE GENERA	AASMF	1
388	HH52PFLDC24V	RELAY FUJI HH52P-FL-DC24V CONTROL MINIATURE GENERA	MATRIZST	10
389	HH52PFLDC24V	RELAY FUJI HH52P-FL-DC24V CONTROL MINIATURE GENERA	SILST	9
390	HH52PWLDC24V	RELEVADOR 5A 250V HH52PW-L DC24V FUJI ELECTRIC	MATRIZST	3
391	HH54PFLDC24V	RELAY CONTROL MINIATURE GENERAL PURPOSE 4PDT, 24 V	MATRIZST	1
392	HH54PLDC24V	RELAY FUJI ELEC HH54P-L DC24V MINIATURE CONTROL RE	SILMO	2
393	HH54PWFLDC24V	HH54PW-FL DC24V RELEVADOR ENCAPSULADO MINIATURA 4P2T 24VDC FUJI ELECTRIC	MTYVI	6
394	HH62PFDC24V	MOD. HH62P-F DC24V, RELEVADOR DE CONTROL FUJI ELEC	MATRIZST	4
395	HH62PFLDC24V	RELAY FUJI ELECTRIC HH62P-FL-DC24V CONTROL MINIATU	AAGMC	3
396	HH62PFLDC24V	RELAY FUJI ELECTRIC HH62P-FL-DC24V CONTROL MINIATU	MATRIZST	2
397	PEB4D	SENSOR DE PROXIMIDAD PE-B4D FUJI ELECTRIC	MATRIZST	2
398	PEB4DB	SENSOR DE PROXIMIDAD PE-B4DB FUJI ELECTRIC	MATRIZST	2
399	RB105DE	RELEVADOR ENCAPSULADO 24V DC #RB105-DE *FUJI	SILMO	1
400	RS4NDE	BASE DE RELEVADOR 24V #RS4N-DE *FUJI	AAGMC	3

401	RZ54X1	FINGER PROTECTION COVER #RZ54X1 MCA FUJI	SILMO	3
402	SC0G	SC0G RELEVADOR # SC-OG *FUJI	MATRIZST	2
403	SC0SC13AA	CONTACTOR TIPO SC-0 SC13AA FUJI ELECTRIC	MATRIZST	6
404	SC1N	CONTACTOR MAGNETICO (3NC0T0122) SC-1 , 110 V. *FUJ	CHIVI	2
405	SC1N	CONTACTOR MAGNETICO (3NC0T0122) SC-1 , 110 V. *FUJ	MATRIZST	1
406	SC40	CONTACTOR TRIFASICO MOD. SC-4-0 110V 20AMP FUJI	MATRIZST	5
407	SCE02100VAC	SC-E02 100 VAC CONTACTOR FUJI ELECTRIC	MATRIZST	3
408	SCE02G200VDC	MOD. SC-E02/G-200VDC, CONTACTOR FUJI	MATRIZST	2
409	SCE04110VAC	SC-E04-110VAC SC-E02 Fuji Electric IEC Contactor,	MATRIZST	12
410	SCE05110VAC	CONTACTOR # SC-E05-110VAC *FUJI	MATRIZST	2
411	SCN2	SCN2 CONTACTOR TRIFASICO 110 V MARCA FUJI	AAP6	1
412	SCN2Z56AC220V	CONTACTOR FUJI ELECTRIC SC-N2/Z56 AC220V, FUJI #SC	MATRIZST	2
413	SCN4GDC24V	SC-N4/G DC24V MAGNETIC CONTACTOR FUJI ELECTRIC	MATRIZST	12
414	SCN5	SCN5 CONTACTOR CON BOBINA DE 100V #SC-N5 *FUJI. CO	CHIVI	1
415	SF20B1A202	SF20B1A-202 CONTACTOR 200-220 VAC 2NC FUJI	MATRIZST	2
416	SK06LE10	CONTACTOR MOD. SK06L-E10, 24 V. DC 1NO MARCA FUJI	MATRIZST	2
417	SK12LE10	CONTACTOR 24VDC 12A SPST-NO #SK12L-E10 MCA FUJI	AAP6	1
418	SS3013ZD3	SS301-3Z-D3 CONTACTOR DE ESTADO SOLIDO FUJI ELECT	MATRIZST	2
419	SZA02	SZ-A02 CONTACTO AUXILIAR FUJI ELECTRIC	MATRIZST	40
420	SZA11	SZA11 BLOCK DE CONTACTO AUXILIAR MARCA FUJI	MATRIZST	13
421	SZA11	SZA11 BLOCK DE CONTACTO AUXILIAR MARCA FUJI	SILST	3
422	SZA20	SZA20 CONTACTOR *FUJI ELECTRIC # SZ-A20	MATRIZST	3
423	SZA22	SZ-A22 BLOCK DE CONTACTO AUXILIAR 2NO-2NC	MATRIZST	16
424	SZA31	SZ-A31 AUXILIARY CONTACT BLOCK FUJI	MATRIZST	5
425	SZA40	RELAY ACCESSORIES AUXILIARY CONTACT BLOCK FOR CONT	MATRIZST	1
426	SZAS1	RELAY ACCESSORIES AUXILIARY CONTACT BLOCK FOR ELEC	MATRIZST	30
427	SZAS2	SZ-AS2, CONTACTO AUXILIAR PARA SC-N2	MATRIZST	30
428	SZGMN1110	SZ-GM/N1-110 BOBINA 110-120VAC PARA CONTACTOR ODYS	MATRIZST	7
429	SZGMN2S110	SZ-GM/N2S-110 BOBINA 110VFUJI ELECTRIC	MATRIZST	5
430	SZRM	SZRM CONTACTOR MECANICO FUJI ELECTRIC	MATRIZST	1
431	SZRW1	SZRW1 KIT DE CONEXION FUJI ELECTRIC	MATRIZST	1
432	SZZ32	SZ-Z32 COIL SURGE SUPPRESSION UNIT FUJI ELECTRIC	MATRIZST	3
433	SZZ35	SURGE ABSORBER AC100-250V NI #SZ-Z35 MCA FUJI	MATRIZST	3
434	SZZ45	SUPRESOR 100-240VAC #SZ-Z45 MCA FUJI	MATRIZST	3
435	SZZ5	COIL SURGE SUPPRESSION SZ-Z5 FUJI	MATRIZST	2
436	SZM1E	MAIN CIRCUIT SURGE SUPPRESSION FRONT MOUNTING FOR	MATRIZST	2
437	TP58X1	SOCKET RELAY #TP-58X1 MCA FUJI	SILMO	1
438	TP814X1	RELAY SOCKETS SCREW TERMINAL DIN RAIL 4 #TP814X1 M	AAGMC	8
439	TRON3036054	TR-ON/3 0.36-0.54 RELEVADOR TERMICO DE SOBRECARGA	MATRIZST	10
440	TRON3913	RELAY, OVERLOAD - MFG: FUJI ELEC PN: TR-ON/3 9-13	AAP6	1